


EMAG IGNITION SYSTEM WITH MAINTENANCE MODE SWITCH

BASED ON BOB NUCKHOLLS Z-33 'MAINTENANCE / HAND PROP OPTION FOR E-MAGS-P-MAGS' SCHEMATIC
VISIT.SUPPORT.SUBSCRIBE TO WWW.AEROELECTIC.COM

DRAFT

DRAFT



FWL = FIREWALL
PNL = INSTRUMENT PANEL GROUND BUS

Note 1: Wires with no size indicated are supplied with, and permanently attached to, relevant components
Note 13: Ignition maintenance mode switch inaccessible in flight.

REV E 12/04/06

Figure D-2. Ignition System

www.rvproject.co.uk